

## Technical Data & Instruction Sheet

### PRODUCT BENEFITS

Enriches Color

Protects against water and oil based stains

Interior and exterior use, weather and UV resistant

Imparts wet look

### RECOMMENDED SURFACES

Natural stones such as Sandstones, Granite, Limestone, Travertine etc.

### AVAILABLE SIZES

1 Ltr, 5Ltrs, 20 Ltrs

### COVERAGE

65-300 sq. ft. per ltr, depending on the porosity of the stone

### EXPECTED WEAR

3-5 years on interior surfaces and 1-3 years on exterior surfaces

### TECHNICAL INFORMATION

Form: Liquid

Specific Gravity: 0.85

Flash Point: NA

Freeze point: 0°C

pH: 8-9

### VOC CONTENT

<650gms/ ltr

### DIRECTIONS

Read entire label before using. Use only as directed. Always test on a small area with a 24 hours curing to check desired results. Make sure surface is clean and free of waxes, dirt and coatings. WL Barrier may be applied to damp surfaces only after surface is completely dry. Ensure that that area is well ventilated during the application and the surface is dry. Surface temperature should be between 10°C and 35°C.

1. Ensure area is well ventilated during application and surface is dry. Use respirator. Follow respirator manufacturer's instructions for use.
2. Mask any surface not intended to be treated.
3. Liberally apply an even coat using a paint brush, roller or cloth. **DO NOT USE SPRAYER**
4. Allow WL Barrier to penetrate the surface for 15-30 minutes. During this time, spread WL Barrier over entire area to ensure even penetration. Remove excess WL Barrier by wiping out entire surface thoroughly with clean and dry towels. **DO NOT ALLOW EXCESS WL BARRIER TO DRY ON SURFACE.**
5. A second coat may be needed for porous, absorbent surfaces and should be applied 30-40 minutes after initial application as directed in steps 2-3.
6. 15-30 minutes after entire application, wipe the entire area with clean dry towels to wipe the excess WL Barrier. To remove residue, reapply a thin coat of WL Barrier, allow to dwell for 2-3 minutes, agitate with a dry nylon pad and dry thoroughly with clean, dry towels.
7. If excess WL Barrier is not wiped off, residue appears, wipe entire surface, with a trowel dampened with WL Barrier.
8. A full cure is achieved after 24-72 hours; foot traffic may begin after 6-8 hours.
9. Clean tools with mineral spirits immediately after application and allow them dry in a well ventilated

### METHOD OF APPLICATION

**DO NOT USE POWER SPRAYER.** Better results will be obtained using a paint brush, pad or roller. For Larger jobs use pump-up garden sprayer. **USE GLOVES, GOGGLES & RESPIRATORS WHILE APPLYING.**

### STORAGE AND HANDLING INSTRUCTIONS

May be harmful if swallowed. May cause skin, eye and respiratory irritation. Do not spray. Avoid prolonged exposure to vapors. Use in a well ventilated area. Do not ingest. **KEEP OUT OF THE REACH OF THE CHILDREN.** Do not freeze or store above 40° C. Do not mix with other chemicals.

### EMERGENCY/ FIRST AID PROCEDURES

Ingestion: Do not induce vomiting. Call a physician

Eye Contact: Flush thoroughly with water for at least 15 minutes. Remove contact lenses, if applicable, and continue flushing. Call a physician if eye irritation persists.

Skin Contact: Wash skin with mild soap and water. Call a physician if skin irritation persists. Wash clothes before wearing again.

Inhalation: Remove to fresh air. Call a physician if respiratory irritation persists.

*The above information is based on the latest stage of our development and application technology. Due to multiplicity of influencing factors, this information must be considered as non-binding. Because conditions of use are outside our control, we make no warranties, express or implied, and assume no liability in connection with any use of this information.*